

About this document

This document gives instructions for locating and clearing faults. The procedures in this document are based on the assumption that the Meridian 1 is properly installed (for example, all card locations, option switch settings, and cable connections are correct) and was fully operational before the fault.

To use this document, you should have a basic knowledge of Meridian 1 operation and maintenance. (Contact Northern Telecom Training Centers for information on courses.) You should also read and fully understand *Meridian 1 general maintenance information* (553-3001-500) before attempting to clear faults.

This document does not provide procedures for replacing equipment. See *Meridian 1 hardware replacement* (553-3001-520) to replace faulty equipment.

References

See the *Meridian 1 planning and engineering guide* for:

- *Meridian 1 system overview* (553-3001-100)
- *Spares planning* (553-3001-153)
- *Meridian 1 equipment identification* (553-3001-154)

See the *Meridian 1 installation and maintenance guide* for:

- *Meridian 1 system installation procedures* (553-3001-210)
- *Circuit card installation and testing* (553-3001-211)
- *Telephone and attendant console installation* (553-3001-215)
- *Meridian 1 general maintenance information* (553-3001-500)
- *Meridian 1 hardware replacement* (553-3001-520)

See the *X11 input/output guide* for a description of all administration programs and maintenance programs, and to the *X11 system messages guide* for interpretation of system messages.